


12' × 12' Metal Patio Wood Gazebo

ASSEMBLY MANUAL



Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;



-It would be much easier to assemble the product with three or more people;

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.

1




x 16

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.







2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo

3



Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like ② shows.

IMPORTANT:
Anchor is not recommended





A 4x Wood Pole



C 4x Beam




C1 4x Beam



E 4x Corner Roof Bar



E1 4x Corner Roof Bar Connector



E2 4x Roof Bar



F 8x Solidfying Bar



H 4x Finishing Bar




J 4x Finishing Bar




K 4x Finishing Bar




K1 4x Finishing Bar




L1 4x Roof Panel




L2 4x Roof Panel




L3 4x Roof Panel




L4 4x Roof Panel




M1 4x Roof Panel




(M2) 4x Roof Panel




(M3) 4x Roof Panel




(M4) 4x Roof Panel




(M5) 4x Roof Panel




(M6) 4x Roof Panel



(M7) 4x Roof Panel



(M8) 4x Roof Panel




(Q) 4x Plastic Bar




(T) 4x Track




(T1) 4x Track




(B) 4x Base




(B1) 4x Base Cover




(B2) 4x Bracket




(B3) 4x Bracket




(C2) 4x Union Bar




(R) 4x Corner Solidifying Bar




(R1) 4x Corner Solidifying Bar




(S) 1x Inside Roof Cover




(S1) 1x Outside Roof Cover



(S2) 1x J-Hook



(U) 4x Bracket




(U1) 4x Bracket


	<p>U2 4x Bracket</p>	<p>U3 4x Bracket</p>	<p>V 112x Hook</p>	<p>W 116x Spacer</p>
	<p>X 4x Joint Cover</p>	<p>X1 4x Corner Cover</p>	<p>X2 4x Finishing End</p>	<p>X3 12x Finishing End</p>
	<p>Y 4x Solid Sidewall</p>	<p>Y1 4x Mosquito Sidewall</p>	<p>Y2 1x Small Mesh</p>	<p>Z 72x Plastic Clips</p>
	<p>Z1 8x Plastic Clips</p>	<p>Z2 8x Plastic Clips</p>	<p>S6 S4 1 1x</p>	<p>ST6.3x15 2 24x</p>
	<p>ST5x16 3 24x</p>	<p>ST5x30 4 16x</p>	<p>M6 5 132x</p>	<p>M6x38 6 16x</p>
	<p>M6x10 7 8x</p>	<p>M6x16 8 144x</p>	<p>M6x25 9 8x</p>	<p>M6x28 10 72x</p>
	<p>M6x45 11 4x</p>	<p>M6x50 12 32x</p>	<p>ST6.3x35 13 32x</p>	<p>ST8x30 14 16x</p>
	<p>D6.6*2 15 16x</p>	<p>M3x65 16 1x Drill</p>	<p>M8x160 17 16x</p>	<p>M8 18 16x</p>



A 4x



B 4x



B1 4x



ST6. 3X35

13 16x





M3x65

16 1x


Pole Assembly:

X4


B1



(1) Put Part #B on the bottom of Part #A, after adjusting the position, use Drill #16 to drill holes at the holes in Part #B.



(2) Secure Part #B and Part #A with 4 Screws #13.




(3) Cover Part #B1 on Part #B.

(4) Repeat the above procedures to assemble the other 3 Part #A.


Beam Assembly:



C 4x



C1 4x



C2 4x



X 4x




1 1x




M6x16


8 40x




(1) Insert Part #C2 into Part #C1 and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #C and secure with 3 Bolts #8.



(4) Insert Part #X into the beam and secure with 1 Bolt #8.






(3) Connect Part #C1 and Part #C through Part #C2.




(5) Secure the bottom of Part #X and Part #C/C1 with 3 Bolts #8.

(6) Repeat the above procedures to assemble the other 3 beams.

X4



(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 7 plastic hooks).



X4

3

(2) Repeat the above procedures for the other 3 track #T & T1.



S4


1 1x



M6x16


8 24x

(1) Use 6 Bolts #8 to fix the track T & T1 to the beam C & C1.




4

(2) Repeat the above procedures for the other 3 beams.




1 1x




ST8X30

14 16x




M8X160

17 16x




M8


18 16x




- (1) Connect Part #C1 to Part #A with 2 Bolts #17, and fix from the other side with 2 Nuts #18.(The first row of screw holes)
- (2) Connect Part #C to Part #A with 2 Bolts #17, and fix from the other side with 2 Nuts #18.(The second row of screw holes)
- Secure Part #C & #C1 with 4 Bolts #14.
- (3) Repeat the above procedures to assemble the other 3 corners.



B2 4x



B3 4x




1 1x




M6x16

8 16x




(1) Affix Part #B2 and Part #B3 to the Beam with 4 Bolts #8.




(2) Repeat the above procedures to assemble the other 3 corners.

⚠ Please don't tighten all bolts.




(1) Affix Part #R to the Part #B3 with 2 Bolts #6, 2 Washers #15 and 2 Nuts #5.

(2) Affix Part #R1 to the Part #B2 with 2 Bolts #6, 2 Washers #15 and 2 Nuts #5.




(3) Use Drill #16 to drill holes in the holes reserved for Part #R/#R1.

(4) Affix Part #R and Part #R1 to the posts with 4 Bolts #13.




(5) Repeat the above procedures to assemble the other 3 corners.


⚠ Please don't tighten all bolts.



(R) 4x



(R1) 4x



(1) 1x



M6

(5) 16x



M6x38

(6) 16x



ST6. 3X35

(13) 16x



D6. 6*2

(15) 16x



M3x65

(16) 1x




X1 4x




ST5x16


3 16x




(1) Cover the corner with Part #X1.




(2) Secure with 2 Self-tapping Screws #3. (from top to bottom)




(3) Secure with 2 Self-tapping Screws #3. (from bottom to top)








U 4x



ST5x30


4 16x

(1) Connect Part #U to Part #A with 4 Bolts #4.



(2) Repeat the above procedures to assemble the other 3 corners.

▲ Tighten all bolts.



E 4x



E1 4x



S4


1 1x



M6x16


8 8x

Assemble the 4 Corner Roof Bars:




(1) Connect Part #E1 and Part #E with 2 Bolts #8

.



(2) Repeat the above procedures to assemble the other 3 corner roof bars.



(S) 1x



(1) 1x




M6x16

(8) 16x




Please have a freestanding ladder ready at the center of the gazebo.

(1) Place 4 Part #E1 on the 4 corners of Part #S.
Secure with 8 Bolts #8 (from bottom to top)

ATTENTION: You can also finish this step on the ground and then lift 4 corner roof bars and inside roof connector to the top together.
(Need 2 people and 2 ladders)












Outside View



Inside View

(2) Place 4 Part #E on 4 Part #A; Secure with 4 Part U and 8 Bolts #8.

Middle Roof Assembly:



✓ S4

1 1x




M6x16

8 12x


Outside View

(1) Place Part #E2 on part #S.
Secure with Bolt #8 (from bottom to top).




Inside View

(2) Connect Part #E2 and the Assembled Beam(C&C1) with part #U1.
Secure with 2 Bolts #8 .
(3) Repeat the above procedures to assemble the other 3 sides.



F 8x



U3 4x



1 1x



M6x10

7 4x




M6x16

8 8x


Solidifying Bar Assembly:

(1) Insert Part #U3 into 2 Part #F.


(2) Attach 2 Part #F to Part #E2 with 1 Bolt #7 and 2 Bolts #8.



Inside View



Outside View



(3) Repeat the above procedures to assemble the other 3 sides.



U2 4x





1 1x



M6x16



8 12x




Inside View




- (1) Insert Part #U2 into 2 Part #F.
- (2) Secure with 2 Bolts #8.
- (3) Secure them to Part #E with Bolt #8.








Install the Plastic Bar #Q to the Mesh #Y2.

Q 4x




Y2 1x








(S1) 1x




(S2) 1x

- (1) Place the Outside Roof Cover #S1 on the inside Roof Cover #S.
- (2) Align the holes and use 1 Hook #S2 to secure Mesh #Y2 to the inside Roof Cover (From Bottom to Top).





J 4x



1 1x



ST6.3x15

2 4x



M6





5 8x




M6x16

8 8x

Use plastic bar #Q to assemble the small mesh #Y2 and finishing bar #J to the middle roof tube #E2.



Inside View






(X3) 4x




ST6.3x15


(2) 4x

Use 4 Screws #2 to secure the finishing end #X3 and finishing bar #J to the corner roof tube #E.



Inside View






(L1) 4x (L2) 4x (L3) 4x (L4) 4x



(Z) 16x




(Z1) 8x






(Z2) 8x

Small Roof Panel Assembly:




⚠ Please install Plastic Clips in strict accordance with the instructions.



20

Attach Part #Z,#Z1,#Z2 by lightly tapping with screwdriver.





(H) 4x



ST6.3x15




(2) 4x

ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #L1 and Part #L2 into the frame.

(2) Insert Part #L3 and Part #L4 into the frame.



(3) Attach Part #H to Part #E2, securing with Screw #2.

(4) Repeat the above procedures to assemble the other 3 sides.




(X3) 4x




ST6.3x15

(2) 4x

(1) Place 2 Part #H on Part #E1;
put on Part #X3 and secure with Self-tapping Screw #2.




Outside View



(2) Repeat the above procedures to assemble the other 3 corners.




M1 4x




M2 4x



M3 4x



M4 4x



M5 4x



M6 4x



M7 4x




M8 4x





Z 56x

23





Section View








▲ Part #W should be inserted between roof panels and solidifying bar or beams, then secure with bolts and nuts.




Big Roof Panel Assembly:





(W) 12x



(1) 1x



M6


(5) 12x




M6x28

(10) 12x


ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #M1 and Part #M2 into the frame.





(2) Insert Part #M8 and Part #M7 into the frame.




(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

Beam





(W) 20x



(1) 1x




M6

(5) 20x



M6x28

(10) 12x




M6x50

(12) 8x


ATTENTION: The bigger roof panel need to cover the smaller one.

(1) Insert Part #M3 into the frame.





Solidifying Bar

(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(2) Insert Part #M6 into the frame.




Beam

(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

(5) Repeat the above procedures to assemble the opposite side.



(W) 24x




(1) 1x



M6

(5) 20x




M6x25

(9) 4x



M6x28

(10) 12x




M6x50


(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #M4 into the frame.



(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.




(2) Insert Part #M5 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.

(5) Repeat the above procedures to assemble the opposite side.



(W) 12x



(1) 1x



M6



(5) 12x





M6x28

(10) 12x


ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #M1 and Part #M2 into the frame.




(2) Insert Part #M8 and Part #M7 into the frame.




(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.



(4) Repeat the above procedures to assemble the opposite side.



(W) 20x



(1) 1x



M6

(5) 20x



M6x28

(10) 12x




M6x50


(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #M3 into the frame.



(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(2) Insert Part #M6 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

(5) Repeat the above procedures to assemble the opposite side.



(W) 24x



(1) 1x



M6

(5) 20x




M6x25

(9) 4x



M6x28

(10) 12x





M6x50


(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #M4 into the frame.



(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.




(2) Insert Part #M5 into the frame.



(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.

(5) Repeat the above procedures to assemble the opposite side.



(W) 4x



(1) 1x



M6



(5) 4x




M6x45

(11) 4x


(1) Place Part #W between roof panels and Part #E2. Then secure with Bolt #11 and Nut #5.



(2) Repeat the above procedures to assemble the other 3 sides.



(K) 4x



(K1) 4x





(X2) 4x



ST6.3x15

(2) 4x

(1) Place Part #K and Part #K1 on Part #E2;
Put on Part #X2 and secure with Screw #2.



(2) Repeat the above procedures to assemble the other 3 sides.




X3 4x



ST6.3x15

2 4x




- (1) Place Part #K1 and Part #K on Part #E;
Put on Part #X3 and secure with Self-tapping Screw #2.
- (2) Repeat the above procedures to assemble the other 3 corners.




ST5x16

3 8x




- (1) Attach roof panels to finishing bars with 2 Self-tapping Screws #3.
- (2) Repeat the above procedures to assemble the other 3 sides.





Y1 4x

Mosquito Netting Assembly:



Y1



Y1

Inside Track

7 Hooks

Y1

7 Hooks

Y1

7 Hooks

7 Hooks

7 Hooks

Y1


7 Hooks

Y1

7 Hooks




7 Hooks

Y1



Y 4x

Curtains Assembly:



7 Hooks

Y

7 Hooks

7 Hooks

7 Hooks

Y

7 Hooks

Y

7 Hooks


Y

Outside Track

7 Hooks

7 Hooks

Y



WOOD CARE GUIDELINES

Wood requires some care and attention over its lifetime to ensure a long-lasting beautiful finish. Proper cleaning and maintenance will keep your wood products looking beautiful for a long time. Please follow these guidelines to maintain your wood surfaces.

- **Fading and weathering:** Wood is a natural product and is expected to change over time. Long periods of sun exposure can naturally lead to color fading. Weather extremes, temperature fluctuations, and humidity highs/lows cause wood to expand and contract, possibly leading to warping and cracking. Knots and small surface cracks are naturally occurring and do not affect the strength of the product.
- **Keeping dry:** Prolonged moisture and high or low humidity can be harmful for wood. Cracking or splitting from extremes outside of the normal humidity range of 35-65% are not covered by our warranty. Preventing prolonged exposure to moisture is advisable.
- **Cleaning:** Frequent light cleaning is recommended. Dust regularly using a slightly damp soft cloth, and then wipe dry (following the direction of the wood grain). For more thorough cleaning, use a soft cloth and a gentle soap solution (dilute ¼ cup mild dishwashing liquid soap with 1 gallon of warm water). Rinse with water, and then immediately dry the surfaces using a soft cloth. Do not use bleach, acid, or other solvents on any metal parts or surfaces. Minor stains or scratches can be lightly buffed with No.0000 steel wool, followed by an application of good quality wood-care oil, wiping in the direction of the grain.
- **Annual sealing:** It is advisable to annually maintain the wooden parts with a sealant or outdoor wax/oil to protect and enhance the wood surfaces. Twice yearly, after cleaning, apply a good quality wood-care oil or water-based sealant to the surfaces. Recommended options are outdoor water-based sealant, linseed, teak, or tung oil. Refer to the manufacturer's specific instructions for application. It is best to try on a small section of wood, then if satisfied with the result, continue the application, taking care to avoid any metal surfaces.
- For further questions and concerns, please contact:
contactus24service@gmail.com



**Call us First !
DO NOT RETURN TO STORE**

For immediate help with assembly or product information

call our number:
(951)213-4742

Or E-mail:

contactus24service@gmail.com

Our staff is ready to provide assistance

M-F 9:00 AM to 5:00 PM EST